

USING THE HEADSET OR SPEAKER

- 1) Use the Speaker Button  to turn speaker ON/OFF.
- 2) Use the Headset button  to use the headset once it had connected.



MAKING A CALL

- 1) Take Handset/Headset off-hook or press Speaker button or an available LINE key (activates speakerphone).
- 2) The line will have dial tone and the corresponding line's LED will turn green.
- 3) If you wish, select another LINE key (alternative SIP account).
- 4) Enter the phone number.
- 5) Press the SEND button  or press the “#” key.



Grandstream

GXP1610/1620/1625/1628/1630

IP Phone

Quick User Guide

Basic Phone Operation
For detailed information please consult the GXP1610/1620/1625/1628/1630 User Manual available at: www.grandstream.com

- 2) Resume: Resume call by pressing the corresponding blinking LINE.

CALL TRANSFER

Assuming that you are in a call and wish to transfer the call to another party.

Blind Transfer:

- 1) Press transfer button.
- 2) Dial the number and  press the send button  to complete transfer of active call.

REDIAL

- 1) Take the phone off-hook.
- 2) Press the SEND button  or press the “REDIAL” soft key.
- Note:** The phone will redial using the same SIP account as was used for the last call.

ANSWERING CALLS

Single Incoming Call:

- 1) Answer call by taking Handset/Headset off hook or pressing SPEAKER or by pressing the corresponding account LINE button.
- Multiple Incoming Calls:**
 - 1) When there is a call waiting, users will hear a Call Waiting tone.
 - 2) The next available line will flash red.
 - 3) Answer the incoming call by pressing its corresponding LINE button.
 - 4) The current call will be put on hold.
 - 5) Toggle between the calls using the LINE button.

ENDING A CALL

- End a call by pressing the “EndCall” soft key or hang up the phone.
- CALL HOLD/RESUME**
 - 1) Hold: Place a call on ‘hold’ by pressing the hold button. 

VOLUME ADJUSTMENTS

- Use the volume button to  adjust the ring volume when the phone is idle.
- Press the volume button during an active call to adjust the call volume.

- 3) When the call is established to the third party, press the “ConfCall” soft key to initiate 3-way conference.
- 4) Repeat step 1-3 to add the fourth party into the conference (GXP1630 only).

Cancel a Conference Call:

- 1) Press “Cancel” soft key in conference dialing screen to resume the two-way conversation.

Hold The Conference:

- 1) Press hold button  to hold the conference call with all parties are on hold;
- 2) Press “ReConf” soft key to resume conference call; or select the corresponding blinking LINE to speak with an individual party.

End The Conference:

- The conference will be terminated for all three parties if the conference initiator hangs up or presses “EndCall” soft key.

VOICEMAIL MESSAGE

- A blinking red MWI (Message Waiting Indicator) indicates a message is waiting.
- 1) Press the Message button to retrieve the message. An IVR will prompt the user through the process of message retrieval.
- 2) Press a specific LINE to retrieve messages for a specific line account.

- Note:** Each account requires a voicemail portal number to be configured in the “voicemail user id” field.

MUTE/DELETE

- 1) Press the  MUTE button to mute/unmute the microphone.
- 2) The Mute icon  indicates whether the microphone is muted.

VOLUME ADJUSTMENTS

- Use the volume button to  adjust the ring volume when the phone is idle.
- Press the volume button during an active call to adjust the call volume.